

# PARTS & SERVICE NEWS

REF NO.	AA98166C
DATE	March 19, 2002

*This Parts and Service News supersedes the previous issue AA98166A dated March 22, 1999 and AA98166B dated August 3, 2000. Both previously issued Parts and Service News should be discarded.*

**SUBJECT:** RELOCATION OF DESICCANT AIR DRYER

**PURPOSE:** This publication updates and corrects Serial Numbers published previously. To introduce a new Air Dryer (PC0778) and improve its functional efficiency by reducing the air inlet temperature thru physical relocation.

**APPLICATION:** WA800-2 and WA900-1 Wheel Loaders  
S/N's WA800-2LC - A20003, A20020 & Higher  
S/N's WA900-1LC - A20008 & Higher  
S/N's WA800-2L - A20001 thru A20019  
S/N's WA900-1L - A20001 thru A20007

**FAILURE CODE:** 450099

**DESCRIPTION:** Remove present Air Dryer and install new Air Dryer to the L.H. ROPS post.  
Install Air Expansion Tank.  
Install Air Dryer Purge Tanks.  
Install larger diameter air hoses.

## INTRODUCTION:

In some environments and/or duty cycles, the rear frame location of the existing Air Dryer will allow the air inlet temperature to reach a high temperature such that the cooling of air, and moisture evaporation process, is not complete.

This Parts and Service News announces a new Air Dryer and physical relocation of the air dryer, addition of an expansion tank, purge tanks, and a reworking of the air supply system. Tests have shown that this improvement will reduce the air dryer inlet temperature to 150°F (66°C) or less, thereby improving the functional efficiency of the Air Dryer.

## FIELD REWORK

The Field Rework consists of:

1. Removing the existing Air Dryer from the current rear frame location and install new the new Air Dryer on L.H. ROPS post (Figure 1).
  - Welding of mounting pads is required (Figure 2)
  - L.H. Deck plate requires 70 x 140mm cut-out to allow for piping installation (Figure 2).
2. Installing a new Air Expansion Tank at the former air dryer location and installing new Purge Tanks are on (Figure 1).
3. Installing new, larger diameter air supply hoses where applicable and changing the routing of lines as necessary (Figure 3).
  - Welding of mounting pads for clamps is required.

## PARTS REMOVAL

1. Remove parts as shown in Figure 1.
2. Remove parts as shown in Figure 2.





FIGURE 1. AIR DRYER PIPING (FIGURE 3581 from PARTS CATALOG)

Remove parts with **CIRCLED** callouts.

- |                                   |                             |                                    |
|-----------------------------------|-----------------------------|------------------------------------|
| [ 2]. Hose (427-W90-1470)         | [14]. Hose (427-W90-1490)   | [32]. Hose (07287-01910)           |
| [ 3]. Elbow (427-W90-1411)        | [24]. Bolt (01010-81035)    | [33]. Band (08034-20519)           |
| [ 4]. Elbow (427-W90-1420)        | [25]. Washer (01643-31032)  | [45]. Clip (362-43-18780) (4 only) |
| [ 5]. Elbow (427-W90-1451)        | [26]. Nut (01580-11008)     | [46]. Band (08034-20519)           |
| [ 6]. Air Dryer Assembly (PC0114) | [27]. Bolt (01010-81230)    | [47]. Wire (425-W90-1331)          |
| [ 7]. Bracket (427-W90-1440)      | [28]. Washer (01643-31232)  | [48]. Fitting, Adaptor (WA5817)    |
| [ 9]. Hose (427-35-12840)         | [29]. Elbow (427-W90-1460)  | [49]. Harness (427-N81-1120)       |
| [10]. Connector (427-35-12810)    | [30]. Nipple (427-W90-1430) | [50]. Band (08034-00519)           |
| [11]. Elbow (427-W90-1152)        | [31]. Clip (07285-00220)    |                                    |



70323

FIGURE 2. AIR DRYER PIPING (FIGURE 3582 from PARTS CATALOG)

Remove parts with **CIRCLED** callouts.

[ 1 ]. Hose (427-W90-1480)

[ 4 ]. (428-35-11170)

[ 3 ]. Hose (427-35-11720)

[ 6 ]. (427-35-12660)

**PARTS REQUIRED**

\*Existing Parts removed (Figure 1)

<b>Figure 1</b>			
<b>Ref No.</b>	<b>Qty.</b>	<b>Part Number</b>	<b>Description</b>
2	1	427-W90-1470	HOSE
3	1	427-W90-1411	ELBOW
4	1	427-W90-1420	ELBOW
5	1	427-W90-1451	ELBOW
6	1	PC0778	AIR DRYER ASSY.
7	1	427-W90-1440	BRACKET
9	1	427-35-12840	HOSE
10	1	427-35-12810	CONNECTOR
11	1	427-W90-1152	ELBOW
14	1	427-W90-1490	HOSE
24	4	01010-81035	BOLT
25	8	01643-31032	WASHER
26	4	01580-11008	NUT
27	4	01010-81230	BOLT
28	4	01643-31232	WASHER
29	1	427-W90-1460	ELBOW
30	1	427-W90-1430	NIPPLE
31	1	07285-00220	CLIP
32	1	07287-01010	HOSE
33	2	08034-20519	BAND
45	5	036245-18780	CLIP
46	5	08034-20519	BAND
47	1	425-W90-1331	WIRE
48	1	WA5817	FITTING ADAPTOR
49	1	427-N81-1120	HARNESS
50	10	08034-00519	BAND

\*Existing Parts removed (Figure 2)

<b>Figure 2.</b>			
<b>Ref No.</b>	<b>Qty.</b>	<b>Part Number</b>	<b>Description</b>
1	1	427-W90-1480	HOSE
3	1	427-35-11720	HOSE
4	1	428-35-11170	HOSE
6	1	427-35-12660	HOSE

## \*New Parts added (Figure 3 through Figure 10)

Ref. No.	Qty.	Part No.	Description	Remarks
1, Figure 4	4	01010-22308	BOLT	TO MOUNT AIR DRYER BRACKET
2, Figure 4	4	01643-31232	WASHER	TO MOUNT AIR DRYER BRACKET
3, Figure 4	2	01573-22308	SEAT	TO MOUNT AIR DRYER BRACKET
4, Figure 4	1	427-W90-A170	DRYER BRACKET MTG.	ASSEMBLE TO ROPS
5, Figure 4	4	01010-61025	BOLT	TO MOUNT AIR DRYER TO BRACKET
6, Figure 4	4	01643-31032	WASHER	TO MOUNT AIR DRYER TO BRACKET
7, Figure 4	2	PC0778	AIR DRYER DESICCANT	MOUNTED ON ROPS
8, Figure 4	1	427-W90-420	FITTING ELBOW	AIR SYSTEM OUTLET-AIR DRYER
9, Figure 4	1	VC6036	REDUCER BUSHING	AIR SYSTEM OUTLET-AIR DRYER
10, Figure 4	2	E2577	TEE	AIR SYS. OUTLET/COMP. INLET-AIR DRYER
11, Figure 4	2	WB0362	FITTING, ADAPTOR	AIR DRYER OUTLET TO AIR SYSTEM
12, Figure 4	2	WB0468	FITTING, ADAPTOR	AIR SYSTEM OUTLET-AIR DRYER
13, Figure 4	1	HA6165	HOSE	COMP. INLET TO COMP. INLET-AIR DRYER
14, Figure 4	1	HA0718	HOSE	GOV. INLET-AIR DRYER TO GOV. INLET-AIR DRYER
15, Figure 4	1	HA6377	HOSE	AIR SYS. OUTLET TO AIR SYS. OUTLET-AIR DRYER
16, Figure 4	2	WB0347	FITTING TEE	GOVERNOR INLET-AIR DRYER
17, Figure 4	2	R1395	PIPE COUPLING	GOVERNOR INLET-AIR DRYER
18, Figure 4	1	07102-20225	HOSE	GOV. INLET-AIR DRYER TO GOV. EXPANSION TANK
19, Figure 4	1	427-W90-1420	FITTING ELBOW	GOVERNOR INLET-AIR DRYER
1, Figure 5	4	WA4649	CLAMP	EXPANSION TANK DRAIN HOSE CLAMP
2, Figure 5	4	01643-31232	WASHER	EXPANSION TANK DRAIN HOSE CLAMP
3, Figure 5	4	01010-81016	BOLT	EXPANSION TANK DRAIN HOSE CLAMP
4, Figure 5	1	HA1416	HOSE	EXPANSION TANK DRAIN
5, Figure 5	1	WB1106	FITTING-FEMALE	EXPANSION TANK DRAIN
6, Figure 5	1	561-35-62830	JOINT	EXPANSION TANK DRAIN
7, Figure 5	1	23S-4-11220	DRAIN VALVE	EXPANSION TANK DRAIN
8, Figure 5	1	505-4-11460	CHAIN	EXPANSION TANK DRAIN
1, Figure 6	1	HA7763	HOSE	PURGE TANK OUTLET-AIR DRYER TO PURGE TANK
2, Figure 6	1	HA7763	HOSE	PURGE TANK OUTLET-AIR DRYER TO PURGE TANK
3, Figure 6	20	01571-01218	CAPSCREW	MOUNTING HOSES
4, Figure 6	20	01010-31216	SEAT	MOUNTING HOSES
5, Figure 6	20	01643-31445	FLAT WASHER	MOUNT HOSES
6, Figure 6	10	TG2562	CLAMP	MOUNT HOSES
7, Figure 6	2	WB0461	STRAIGHT ADAPTOR	PURGE TANK INLET
8, Figure 6	1	427-W90-A350	HOSE	COMP. INLET-AIR DRYER TO EXPANSION TANK
9, Figure 6	4	428-35-11170	HOSE	REUSE EXISTING HOSE
10, Figure 6	10	TG2568	CLAMP	MOUNT HOSES

11, Figure 6	1	427-W90-A371	HOSE	AIR DRYER CHECK VALVE TO WET TANK SUPPLY
1, Figure 7	22	01643-31032	WASHER	VARIOUS LOCATIONS
2, Figure 7	4	TC1233	NUT	MOUNT PURGE TANK
3, Figure 7	2	EG6207	PURGE TANK	MOUNTED NEXT TO EXPANSION TANK
4, Figure 7	6	C5770	PLUG	PURGE TANK
5, Figure 7	2	WB0461	STRAIGHT ADAPTOR	PURGE TANK INLET
6, Figure 7	1	566-35-42350	SAFETY VALVE	EXPANSION TANK SIDE
7, Figure 7	1	07326-10402	FITTING ADAPTOR	EXPANSION TANK SIDE
8, Figure 7	1	07323-30400	FITTING ELBOW	EXPANSION TANK SIDE
9, Figure 7	1	566-35-42690	EXPANSION TANK	REAR FRAME-INSIDE
10, Figure 7	2	566-35-14410	FITTING ADAPTOR	EXPANSION TANK-TOP AND END
11, Figure 7	2	07042-00415	PLUG	EXPANSION TANK
12, Figure 7	1	427-35-A1120	HOSE	EXPANSION TANK TO AIR DRYER
13, Figure 7	1	07822-00402	TUBE	JOINT TO GOVERNOR-EXPANSION TANK
14, Figure 7	1	427-W90-A330	HOSE	GOV. EXP. TANK TO COMP. INLET AIR DRYER
15, Figure 7	1	427-W90-A320	HOSE	AIR COMPRESSOR TO EXPANSION TANK
16, Figure 7	1	427-35-12660	HOSE	REUSE EXISTING HOSE
17, Figure 7	1	427-W90-A430	HOSE	SHUTTLE VALVE TO AIR COMPRESSOR
18, Figure 7	1	427-W90-A150	BRACKET	FOR EXPANSION TANK
19, Figure 7	12	01010-81230	BOLT	MOUNT EXPANSION TANK AND MOUNT SURGE TANK
20, Figure 7	12	01643-31238	WASHER	MOUNT EXPANSION TANK AND MOUNT SURGE TANK
21, Figure 7	1	07238-10315	CONNECTOR	SHUTTLE VALVE AT EXP. TANK
22, Figure 7	4	TG9225	LOCKNUT	MOUNT EXPANSION TANK TO BRACKET
23, Figure 7	4	WA0720	FLAT WASHER	MOUNT EXPANSION TANK TO BRACKET
24, Figure 7	1	427-W90-A310	BRACKET	MOUNT NEXT TO EXPANSION TANK
25, Figure 7	8	01643-31230	WASHER	EXPANSION TANK DRAIN HOSE CLAMP
26, Figure 7	4	01571-01016	SEAT	EXPANSION TANK DRAIN HOSE CLAMP
27, Figure 7	1	07102-20304	HOSE	SHUTTLE VALVE TO GOV. AT EXP. TANK
28, Figure 7	1	208-72-17211	ELBOW	SHUTTLE VALVE AT EXP. TANK
29, Figure 7	1	07324-10300	TEE	SHUTTLE VALVE OUTLET
30, Figure 7	1	427-W90-17710	NIPPLE	SHUTTLE VALVE OUTLET
31, Figure 7	1	195-78-22570	ELBOW	GOV. EXPANSION TANK BRACKET
32, Figure 7	2	EG2565	U-BOLT	ASSEMBLE EXPANSION TANK
33, Figure 7	1	HA7763	HOSE	PURGE TANK OUTLET - AIR DRYER TO PURGE TANK
1, Figure 8	2	WB0261	90 DEGREE FITTING	PURGE TANK OUTLET & AIR SYSTEM OUTLET DRYER
2, Figure 8	2	DD3535	LONG NIPPLE	COMP. INLET AIR DRYER
3, Figure 8	1	566-35-6A110	JOINT	EXPANSION TANK-SIDE
4, Figure 8	1	07043-70312	PLUG	JOINT-EXPANSION TANK-SIDE
5, Figure 8	1	07043-70211	PLUG	JOINT-EXPANSION TANK-SIDE
6, Figure 8	1	07834-00413	FITTING ELBOW	EXPANSION TANK SIDE

7, Figure 8	2	MM0070	CAPSCREW	GOVERNOR-EXPANSION TANK
8, Figure 8	2	01643-30823	WASHER	GOVERNOR-EXPANSION TANK
9, Figure 8	1	07834-00410	ELBOW	GOVERNOR-EXPANSION TANK
10, Figure 8	3	07831-00411	SLEEVE	GOVERNOR-EXPANSION TANK
11, Figure 8	1	07832-00410	NUT	GOVERNOR-EXPANSION TANK
12, Figure 8	1	EH9534	GOVERNOR ASSY.	MOUNTED BELOW EXPANSION TANK
13, Figure 8	1	WB1106	FITTING ADAPTOR	EXPANSION TANK LOWER
14, Figure 8	10	TG2568	CLAMP	MOUNT HOSES
15, Figure 8	4	01010-81016	BOLT	EXPANSION TANK DRAIN HOSE CLAMP
16, Figure 8	22	01643-31032	WASHER	VARIOUS LOCATIONS
17, Figure 8	1	427-W90-A280	ADAPTOR CONV.	GOV. INLET-AIR DRYER
18, Figure 8	1	427-W90-1420	FITTING ELBOW	COMP. INLET-AIR DRYER
19, Figure 8	1	569-35-61120	VALVE, CHECK DOUBLE	ASSEMBLED TO EXP. TANK BRACKET
20, Figure 8	2	01010-80612	BOLT	ASSEMBLE VALVE TO EXP. TANK BRACKET
21, Figure 8	2	01643-30623	WASHER	ASSEMBLE VALVE TO EXP. TANK BRACKET
22, Figure 8	1	07238-10208	CONNECTOR	ENGINE AIR COMPRESSOR
23, Figure 8	1	07324-80100	COUPLING	ENGINE AIR COMPRESSOR
24, Figure 8	1	07325-10100	NIPPLE	ENGINE AIR COMPRESSOR
25, Figure 8	1	427-35-12320	TUBE	ENGINE AIR COMPRESSOR
26, Figure 8	1	421-09-12540	ELBOW	ENGINE AIR COMPRESSOR
Figure 9	1	427-W90-1331	WIRING HARNESS	REWORK (SEE Figure 9)
1, Figure 10	1	08022-14003	TERM (MALE)	SEE Figure 10
2, Figure 10	2	08021-10400	TERM (FEMALE)	SEE Figure 10

### INSTALLATION OF PARTS

1. Weld mounting seats (3, Figure 4).
2. Cut out 70 x 140mm notch in L.H. Deck plate (Figure 4) to allow piping installation.
3. Remove the existing Air Dryer from the current location and discard. Mount new Air Dryer to the L.H. ROPS post (Figure 4).
4. Mount new bracket (4, Figure 4) to ROPS post using capscrews and washers.
5. Install Air Dryer (7, Figure 4) to bracket using capscrews, washers, and nuts.
6. Install Expansion Tank Bracket using capscrews and washers to mounting pads where the previous Air Dryer was formerly mounted.
7. Install Expansion Tank to bracket using U-bolts, washers, and nuts (Figure 6).
8. Install Purge Tank Bracket in new location next to Expansion Tank using capscrews and washers (Figure 6).
9. See page 22 for GOVERNOR TESTING & ADJUSTING.




Figure 3. Air Dryer Desiccant

70307




Figure 4. Air Piping - Upper L.H. ROPS








Figure 5. Rear Frame Air Dryer Piping (Lower)



70313

Figure 6. Rear Frame Air Dryer Piping (Front)



70314

Figure 7. Rear Frame Air Dryer Piping




Figure 8. Air Piping (Rear)




Figure 9. Air Dryer Electrical Schematic




Figure 10. Air Dryer Harness Modifications

- 1. Existing Harness (425-W90-1331)
- 2. Connector (08022-14001)

*NOTE: Remove connector (2, Figure 10) and install connector (08022-14003) supplied in kit.*

**AIR DRYER**

The air dryer is a desiccant type dryer. The wheel loader uses two air dryer units, mounted behind the operator cab.

The air dryer (1, Figure 11) receives hot compressed air from the expansion tank (6), which it cools, dries and filters before sending it to the wet tank (3) located on the right hand deck. This reduces the build up of dirt and moisture in the vehicle air system. The system incorporates separate, isolated purge tanks (2).

The air dryers consist of a housing (light weight aluminum and steel construction) and a spin-off cartridge. Below the cartridge are five ports; the inlet port B receives compressed air from the expansion tank (6). The outlet port A directs clean/dry air to the wet tank (3) and truck air system. The purge port D contains a bleed valve directing air to and from the isolated purge tank. The unloader port C contains an unloader valve that receives a signal from the primary governor. The exhaust port E expels accumulated moisture and contaminants.




FIGURE 11. AIR DRYER DIAGRAM

**COMPONENTS**

1. Air Dryer
2. Purge Tank
3. Wet Tank
4. Secondary Governor
5. Air Compressor
6. Expansion Tank
7. Primary Governor
8. Shuttle Valve

**PORTS**

- A: Outlet/Check Valve  
 B: Inlet Port  
 C: Unloader Port  
 D: Purge Tank Port  
 E: Dryer Exhaust  
 F: Governor Inlet Port  
 G: Compressor Air Inlet  
 X: Governor Exhaust

**OPERATION**

Refer to Figure 12 and 13 for diagrams of the air dryer and related components during the air system charging cycle and the unload and purge cycle.

Note: Only one air dryer is shown in the illustrations. Operation is identical for both.

**Charging Cycle**

Hot, compressed air enters each air dryer (14, Figure 12) through the inlet port B. As the hot air enters the dryer, the air expands, oil and water vapor condense, and accumulate in the sump. The air passes through three filters and a cloth bag that remove carbon and other contaminants. Vapor is absorbed by the desiccant as air travels through the desiccant bed housed in the cartridge. The clean, dry air is then directed out port A to the wet tank (10) and the vehicle air system and simultaneously to the purge tank (1) through the purge port D.

**Purge Cycle**

When air pressure in the wet tank (10, Figure 13) reaches 8.3 kg/cm<sup>2</sup> (118 psi), (primary governor cut-out<sup>a</sup> pressure) air from governor port C flows to the shuttle valve (9) and to the compressor (8), signalling it to stop pumping. This same air flows into the air dryer unloader valve (3), opening exhaust port E.


This action causes a sudden discharge of air through the exhaust port E of the dryer. The filtered, dried purge air, which has accumulated in the isolated purge tank (1), slowly bleeds back through the air dryer. This action regenerates desiccant, cleans filters and expels the contaminants out the exhaust port E and completes the regeneration cycle.

**Stand-by Mode**

When the air system drops to the primary governor regulated cut-in<sup>a</sup> pressure, 7.6 kg/cm<sup>2</sup> (108 psi), the air dryer unloader valve (3) closes as the unloader line pressure evacuates through the exhaust port X of the governor. The compressor is signaled to load and resume pumping.

**Secondary Governor**

The secondary governor will not signal the compressor to unload during normal operation. However, if a blockage occurs in the line between the expansion tank, air dryers, and the wet tank, such as an air dryer element that needs to be replaced, expansion tank pressure may increase to 9.0 kg/cm<sup>2</sup> (128 psi) and the secondary governor will provide the signal to turn the compressor off.




70656

FIGURE 12. CHARGE CYCLE

COMPONENTS		PORTS	
1. Purge Tank	8. Air Compressor	A: Check Valve	E: Dryer Exhaust
2. Bleed Valve	9. Shuttle Valve	B: Dryer Intake	F: Governor Air Supply
3. Unloader Valve	10. Wet Tank	C: Unloader	G: Compressor Air Intake
4. Primary Air Governor	11. Check Valve	D: Purge Tank	X: Governor Exhaust
5. Turbo Valve	12. Dry Tank		
6. Secondary Air Governor	13. Air Dryer		
7. Expansion Tank			

Refer to Figure 14 for Valve Locations:

- VALVES OPEN- Ball Check Valve (5); Unloader Valve (9)  
 VALVES CLOSED- Check Valve (2); Bleed Valve (13); Turbo Valve (7)



70657

FIGURE 13. UNLOAD/PURGE CYCLE COMPONENTS

- |                           |                   |
|---------------------------|-------------------|
| 1. Purge Tank             | 8. Air Compressor |
| 2. Bleed Valve            | 9. Shuttle Valve  |
| 3. Unloader Valve         | 10. Wet Tank      |
| 4. Primary Air Governor   | 11. Check Valve   |
| 5. Turbo Valve            | 12. Dry Tank      |
| 6. Secondary Air Governor | 13. Air Dryer     |
| 7. Expansion Tank         |                   |

- |                  |                          |
|------------------|--------------------------|
| A: Check Valve   | F: Governor Air Supply   |
| B: Dryer Intake  | G: Compressor Air Intake |
| C: Unloader      | X: Governor Exhaust      |
| D: Purge Tank    |                          |
| E: Dryer Exhaust |                          |

Refer to Figure 14 for Valve Locations:

- VALVES OPEN- Ball Check Valve (5); Unloader Valve (9)  
 VALVES CLOSED- Check Valve (2); Bleed Valve (13); Turbo Valve (7)



---

**General Precautions**

Whenever working on or near air systems and components, always observe the following:

1. If the vehicle is equipped with an air-actuated brake system, the vehicle's wheels must be chocked. Block the wheels and make sure the vehicle will not roll, before releasing the brakes and before performing any test and/or isolating the air dryer.
2. Stop the engine when working under a vehicle.
3. Never connect or disconnect a hose or line containing air pressure. Never remove a component or a pipe plug unless you are certain all system air pressure has been exhausted.
4. Always wear safety glasses when working with air pressure. Never look directly into air dryer ports.
5. Never exceed recommended working air pressure.
6. Never attempt to disassemble an air dryer until you have read and understood all recommended procedures. Use only proper tools and observe all precautions pertaining to the use of those tools.

**Removal**

1. Drain the air system.
2. Disconnect heater wiring.
3. Mark the air lines for later reference and disconnect from the air dryer.
4. Remove the lock nuts, washers, and capscrews that attach the air dryer to the vehicle.

**Installation**

1. Position the air dryer. Install the capscrews, washers, and lock nuts.  
Tighten capscrews to 37 ft. lb (80 N.m) torque.
2. Inspect lines and fittings. Replace any that are damaged.
3. Connect all air lines, taking care to match marked line with appropriate port.
4. Connect the heater wiring.

<https://thespareparts.com/>

## Desiccant Cartridge Service

### Symptoms/Actions

1. Regular service interval.

1 year/5000 Hours

*NOTE: The above is a **guideline only**.  
Check the tank(s) on regular basis.  
If moisture exists, replace cartridge.*

2. Water in tanks.

Desiccant cartridge requires regular servicing at intervals determined by compressor duty cycle or type of operation, environment, etc.




Figure 14. Turbo 2000 Air Dryer

#### COMPONENTS

#### PORTS

- |                        |                |
|------------------------|----------------|
| 1. Desiccant Cartridge | A. Check Valve |
| 2. Check Valve Knob    | B. Intake      |
| 3. Check Valve Nut     | C. Unloader    |
| 4. Body Gasket         | D. Purge Tank  |
| 5. Ball Check Valve    | E. Exhaust     |
| 6. Bottom Cap Assembly |                |
| 7. Turbo Valve         |                |
| 8. Seal Retainer       |                |
| 9. Unloader Valve      |                |
| 10. Heater             |                |
| 11. Safety Valve       |                |
| 12. Bleed Valve Nut    |                |
| 13. Bleed Valve        |                |

### Desiccant Cartridge Replacement

1. Drain the air system.
2. Using a strap wrench, turn the desiccant cartridge (1, Figure 14.) counterclockwise and remove it. Discard cartridge.

3. Remove and discard O-ring from adaptor plate stud.

*NOTE: If there is excessive oil in the check valve port, compressor may require servicing.*

4. Clean top surface of adaptor plate and threaded stud.

5. Using grease supplied with cartridge, apply a light coating on the O-ring. Install O-ring on adaptor stud.

6. Apply a generous coat of grease on the new desiccant cartridge gasket surface.

7. Thread new cartridge onto adaptor stud turning clockwise. When gasket contacts adaptor plate, tighten cartridge  $\frac{1}{2}$  Turn only.

**DO NOT OVER-TIGHTEN.**

## Unloader Valve Service

### Symptoms/Actions

#### 1. Dryer won't exhaust.

Start engine and build pressure to just before "cut-out" pressure. Cycle several times. If dryer does not exhaust, replace unloader valve.

#### 2. Air leak at exhaust port during the:

##### a) Charge Mode;

Start engine and build pressure to just before "cut-out". Stop engine. Apply soap solution at exhaust port or listen for air leak at exhaust port. If a leak is present, replace unloader valve.

#### 3. Pressure slow or no build.

Start engine and build pressure to just before "cut-out". Stop engine. Apply soap solution at exhaust port or listen for air leak at exhaust port. If a leak is present, replace unloader valve.

#### 4. Compressor cycles rapidly.

Remove governor line from UNL port on air dryer. Start engine and build to cut-out pressure. Stop engine. If no air leaks are present, replace unloader valve.

## Unloader Valve Replacement

1. Disconnect the unloader air line.
2. Remove the two fasteners that attach the unloader valve retainer (8, Figure 14). Remove the retainer.
3. Remove the unloader valve assembly (9) from the unloader port and discard.

*NOTE: If there is excessive oil in the unloader port, compressor may require servicing.*

4. Clean the unloader port thoroughly.
5. Remove the three (3) O-rings from the retainer and discard.
6. Using lubricant supplied with kit, lightly grease the new O-rings.
7. Install on the retainer the two (2) thickest O-rings. Then install the third (thinner) O-ring.
8. Install the new filter screen in the unloader cavity, open end out.
9. Apply a light coating of grease around the O-ring seat on valve assembly. Install the thin O-ring on the unloader valve seat.
10. Aligning the valve exhaust port with the air dryer exhaust port, install the unloader valve assembly. Use care not to dislodge the O-ring from its seat.

*If the air dryer exhaust port and unloader valve exhaust port do not align, air dryer will not unload.*

11. Install retainer.
12. Apply a light coating of grease on the threads of the two retainer bolts.
13. Install the two retainer bolts and tighten to **10-15 ft. lb. (13.56-20.34 N.m)** torque.
14. Reconnect the unloader air line to air dryer unloader port.

## Bleed Valve Service

### Symptom

1. Water in tanks.
2. Slow or no purge

### Operation Check

Start engine and build air pressure allowing dryer to exhaust. Stop engine. After initial exhaust, air should bleed with decreasing intensity out the exhaust port for approximately 45 seconds. If air fails to bleed as described, replace bleed valve kit.

### Bleed Valve Replacement

1. Drain the air system
2. Disconnect the air line at air dryer purge port.
3. Remove bleed valve nut (12, Figure 14).
4. Remove and discard O-ring, spring and spindle.
5. Clean bleed valve nut and cavity area.
6. Position new spindle in the cavity with spring pocket side out. Install spring.
7. Using grease supplied with kit, apply a light coating on O-ring. Install O-ring on nut.
8. Apply light coating of grease on nut threads. Install nut and tighten to 60 ft. lb. (81.35 N.m) torque.
9. Re-connect air line to air dryer purge port.

## Check Valve Service

### Symptom

1. Dryer frequently unloads.
2. Air continually flows from exhaust port when compressor is in standby mode.
3. Wet tank pressure drops rapidly.

*NOTE: The above symptoms could also lead to turbo valve replacement. A malfunctioning turbo valve will tend to allow pressure to drop to "cut-in" pressure within seconds.*

### Operational Check

Disconnect line at purge port and plug. Start engine and build pressure to "cut-out" pressure. Stop engine. Apply soapy solution around exhaust port. If soap bubbles exist, replace check valve.

### Check Valve Replacement

1. Drain air system.
  2. Disconnect air line from outlet port.
  3. Remove check valve nut (3, Figure 14).
  4. Remove and discard O-ring, spring, spindle, and ball.
- NOTE: If there is excessive oil in the check valve port, compressor may require servicing.*
5. Clean nut and cavity area.
  6. Install new ball in cavity. Next, position spindle with spring pocket facing out. Install spring.
  7. Using grease supplied with kit, apply a light coating on O-ring. Install O-ring on nut.
  8. Apply a light coating of grease to threads of nut. Install nut and tighten to 60 ft. lb. (81.35 N.m) torque.
  9. Re-connect air line to air dryer outlet port.

## Turbo Valve Service

### Symptom

1. Dryer frequently unloads.
2. Air continually flows from exhaust port when compressor is in standby mode.
3. System pressure drops very rapidly.

NOTE: *The above symptoms could also lead to check valve replacement. A malfunctioning turbo valve will tend to allow pressure to drop to cut-in pressure within seconds.*

### Operational Check:

Disconnect line at purge port and plug. Start engine and build pressure to cut-out pressure. Stop engine.  
Apply soapy solution around exhaust port. If soap bubbles exist, replace turbo valve.

### Turbo Valve Replacement

1. Drain the air system.
2. Disconnect the heater wiring. Disconnect the inlet and unloader lines from their respective ports. Mark lines for later assembly.
3. Remove eight bolts from bottom cap and set aside. Discard gasket.
4. Remove turbo nut, valve stop, and valve (7, Figure 14) and discard.
5. Clean cavity area thoroughly.
6. Lightly coat the two small O-ring surfaces and install on piston. Carefully install valve in cavity with tapered side up.
7. Place valve stop on top of valve concave side down.
8. Lightly lube large O-ring and place on nut. Install flat seal into nut.
9. Install nut and tighten to 50 ft. lb. (68 N.m) torque.
10. Place gasket on bottom cap aligning small hole with small check valve. Locate bottom cap so that inlet port is directly below outlet port. Install the eight bolts set aside during disassembly and tighten to 15-20 ft. lb. (20 -27 N.m) torque.
11. Re-connect inlet and unloader lines as previously marked to air dryer.
12. Re-connect heater wiring.

## Heater Assembly Service

### Symptom

1. Dryer won't exhaust.
2. Exhaust port leaks.
3. Cannot build pressure.

### Operational Checks

Thermostat must be cooled to at least 35° F (2°C) to check.

1. Connect an ohmmeter across the heater electrical terminals. The reading should show a closed circuit.
2. If the reading shows an open circuit, replace heater assembly.

### Heater Assembly Replacement

1. Disconnect heater leads.
2. Remove the two screws from heater cover.
3. Remove heater/thermostat assembly (10, Figure 14) and discard.
4. Thoroughly clean entire area.
5. Apply a light coating of anti-seize to the heater element and to the thermostat cavity only. Do not apply this compound to screws.
6. Install new heater. Twist slightly to spread anti-seize. Install new set screw until snug. Set screw will protrude from bottom cap about 0.125 inch (3.18 mm). **DO NOT OVER-TIGHTEN.**
7. Install new thermostat. Coil wires around heater cover posts allowing wires to protrude through slots. Place the two #6-32 x 1.125 inches (2.86 cm) screws in heater cover and attach the thermostat.
8. Fill heater cover with non-corrosive RTV.
9. Connect blue heater wire to a good chassis ground.
10. Connect orange wire to ignition switch.
11. Seal and route heater wires carefully.

**GOVERNOR TESTING AND ADJUSTING**

1. After installation of the parts has been completed, ensure that there are no leaks in the air system, and the governors are working properly. Run the engine and check the cycling pressures of the governors. Adjust if necessary. Refer to the table below for the proper governor specifications.
2. Connect an air supply of 130 psi (9.1 kg/cm<sup>2</sup>) to the supply port on the governor. The supply port is stamped "RES". The thread size of the port is 1/8 PT.
3. Install a 0-200 psi. pressure gauge in the unloader port. The unloader port is the center port and is stamped "UNL". Thread size of the port is 1/8 PT.
4. Remove the rubber cover located on top of the governor.
5. Loosen the locknut on the setscrew.
6. Turn on the air supply and observe the gauge.
7. Increase the pressure until a sudden pressure jump appears on the gauge. This is the current cut-out pressure.
8. Decrease the pressure until the gauge suddenly drops back to 0 psi. This is the cut-in pressure.
9. Rotate the screw on top of the governor to adjust the pressure. Turn the screw clockwise to decrease the pressure. Turn the screw counter-clockwise to increase the pressure. One turn is approximately equal to 16 psi (1.1 kg/cm<sup>2</sup>).
10. Check the pressure after adjusting the screw. If the cut-out pressure is not within the specifications, bleed off the supply pressure, and rotate the screw accordingly. Repeat this step until the proper specification is attained.
11. After the screw has been set to the proper pressure, repeat steps 15 and 16 several times to ensure the pressures are constant. Adjust as necessary.
12. Apply Loctite to the bottom face of the locknut, and tighten the nut. Install the rubber cover.

GOVERNOR SPECIFICATIONS			
GOVERNOR	LOCATION	CUT - IN PRESSURE	CUT-OUT PRESSURE
Primary	Lower RH side of engine	108 ± 4 psi (7.6 ± 0.3 kg/cm <sup>2</sup> )	118 ± 4 psi (8.3 ± 0.3 kg/cm <sup>2</sup> )
Secondary	LH side of rear engine frame under expansion tank	118 ± 4 psi (8.3 ± 0.3 kg/cm <sup>2</sup> )	128 ± 4 psi (9.0 ± 0.3 kg/cm <sup>2</sup> )

## AIR DRYER TROUBLESHOOTING

**Problem:** Air continually exhausts from the exhaust port when the compressor is in the standby mode.

Possible Cause	Remedy
The air dryer check valve is worn.	Clean cavity. Replace check valve assembly.
Turbo valve is damaged or worn.	Clean cavity. Replace turbo valve assembly.
The air dryer unloader valve seal is worn.	Clean cavity. Replace unloader valve assembly.

**Problem:** System air pressure drops rapidly.

Possible Cause	Remedy
Fittings are loose or damaged.	Tighten and/or replace as necessary.
Air reservoir, tubing, or hoses are damaged.	Repair or replace as necessary.
The air dryer check valve is worn.	Clean cavity. Replace check valve assembly.
Turbo valve is leaking.	Clean cavity. Replace turbo valve assembly.
The air dryer unloader valve seal is worn.	Clean cavity. Replace unloader valve assembly.

**Problem:** The air compressor goes into the standby mode but cycles rapidly.

Possible Cause	Remedy
Fittings are loose or damaged.	Tighten and/or replace as necessary.
Air reservoir, tubing, or hoses are damaged.	Repair or replace as necessary.
The air dryer check valve is worn.	Clean cavity. Replace check valve assembly.
Turbo valve is worn.	Clean cavity. Replace turbo valve assembly.
Air governor malfunctioning.	Replace governor valve.
The air dryer unloader valve seal is worn.	Clean cavity. Replace unloader valve assembly.

**Problem:** Air flow from the exhaust port when the air compressor is trying to build up pressure.

Possible Cause	Remedy
The unloader valve is worn.	Clean cavity. Replace unloader valve assembly.
Dirt/foreign material is stuck in unloader valve.	Clean cavity. Replace unloader valve assembly.
Air governor malfunctioning.	Replace governor valve.
Heater assembly malfunctioning. (32°F).	Replace heater assembly.

## AIR DRYER TROUBLESHOOTING (Continued)

**Problem:** The air compressor runs continuously (system pressure will not build).

Possible Cause	Remedy
Fittings are loose or damaged.	Tighten or replace loose or damaged fittings.
Air reservoir, tubing, or hoses are damaged.	Repair or replace damaged items.
The air compressor needs serviced or replaced.	Rebuild or replace the air compressor.
The air dryer unloader valve is worn.	Clean cavity. Replace the unloader valve ass'y.
The air compressor capacity too low for vehicle.	Install larger air compressor.
Line between governor and air compressor is blocked.	Replace the line or remove the blockage.
Air governor malfunctioning.	Replace governor valve.

**Problem:** The air dryer does not unload when the air compressor goes into standby mode.

Possible Cause	Remedy
The line between the air governor and the air dryer unloader port is missing.	Install or replace the air line, or tighten the fittings.
The unloader valve is worn.	Clean cavity. Replace the unloader valve ass'y.
Ice has formed in the unloader valve.	Check heater assembly; replace if necessary.
The heater is malfunctioning.	Check heater assembly; replace if necessary.
The unloader valve sleeve is misaligned.	Align unloader valve sleeve.

**Problem:** The safety valve opens.

Possible Cause	Remedy
The air dryer check valve is blocked.	Clean cavity. Replace the check valve assembly.
The air brake system is blocked down stream from the air dryer.	Remove blockage or replace the necessary components.
The air compressor governor valve is malfunctioning.	Replace the compressor air governor valve.
The safety valve is malfunctioning.	Replace the safety valve.



---

## AIR DRYER TROUBLESHOOTING (Continued)

**Problem:** Water accumulation in air system (tanks).

Possible Cause	Remedy
Desiccant is contaminated.	Replace desiccant cartridge.
The air compressor capacity too low for vehicle.	Install larger air compressor and replace desiccant cartridge.
Bleed valve is malfunctioning.	Clean cavity. Replace bleed valve assembly.
The line between the purge tank and the air dryer purge port is missing, leaking, or damaged.	Install or replace the air line, or tighten fittings.
Line between the compressor and air dryer too short (Insufficient pre-cool).	Fit new line with a minimum length of 6 ft. (1.83 m) copper line or 12 ft. (3.66 m) of steel braided teflon.

<https://hespareparts.com/>




Figure 15. Turbo 2000 Air Dryer Assembly

70399

**TURBO 2000 AIR DRYER ASSEMBLY**

REF NO.	PART NO.	QTY.	DESCRIPTION
1		1	CARTRIDGE, DESICCANT (1)/(2)
2	BF4908	1	BRACKET, MOUNTING
3		1	PLATE, ADAPTOR (1)/(3)
4	BF3710	1	NUT, CHECK VALVE
5	BF3705	1	NUT, BLEED VALVE
6	VJ8001	1	GASKET
7	TD0791	1	CAPSCREW - 3/8" - 16NC X 1 1/4"
8	VS6000	1	VALVE, SAFETY
9	BF3600	1	LABEL, EXHAUST CAUTION
10	PC0114	1	RETAINER, SEAL
11	TR1306	2	CAPSCREW - 1/4" - 20NC X 1"
12		1	HEATER - 24V, 75W (1)/(4)
13		1	SCREW - #8 - 32NC X 1/2" (1)/(1)
14		1	CAP, BOTTOM (1)/(5)
15	BF3704	1	ADAPTER, CARTRIDGE (3)
16	BF3709	1	O-RING (2)
17		1	GASKET (1)/(2)
18	VD9206	3	O-RING (6)
19		2	SPRING (2)/(9)
20		1	SPINDLE, BLEED VALVE (1)/(9)
21		1	COIL, FOAM (1)/(4)
22	WA0057	1	O-RING (4)
23		1	SCREW (1)/(7)
24	BF3708	1	SCREEN, TRASH (7)
25	BF3595	1	WASHER, COMPRESSION (7)
26		1	BALL, 1/2 (1)/(7)
27		1	SLEEVE (1)/(7)
28		1	SPRING (1)/(7)
29		1	PISTON/SPINDLE (1)/(7)
30	BF3601	3	O-RING (7)
31	BF3585	2	O-RING (7)
32	BF3602	1	VALVE, COMPRESSOR UNLOADER (8)
33		2	O-RING (1)/(8)
34	BF3607	1	VALVE, STOP (8)
35	BF3606	1	SEAL (8)
36	BF3605	1	O-RING (8)
37	BF3609	1	VALVE, CHECK (5)
38	BF3608	1	SEAT, CHECK VALVE (5)
39	BF3604	1	SEAT, UNLOADER VALVE (8)

**TURBO 2000 AIR DRYER ASSEMBLY (Continued)**

<b>REF NO.</b>	<b>PART NO.</b>	<b>QTY.</b>	<b>DESCRIPTION</b>
40.		1	SPINDLE (1)/(6)
41.		1	BALL (1)/(6)
42.	370944R1	1	O-RING (3)
NSS	NSS		NOTE: (1) NOT SERVICED SEPARATELY.
KT	BF3703		(2) PART OF CARTRIDGE REPLACEMENT KIT BF3703.
KT	BF5096		(3) PART OF SERVICE KIT BF5096.
KT	BF5098		(4) PART OF SERVICE KIT BF5098.
KT	BF5095		(5) PART OF BOTTOM CAP KIT BF5095.
KT	RK1869		(6) PART OF CHECK VALVE KIT RK1869.
KT	RK0109		(7) PART OF UNLOADER KIT RK0109.
KT	BF4068		(8) PART OF TURBO VALVE KIT BF4068.
KT	BF4067		(9) PART OF BLEED VALVE KIT BF4067.