PARTS & SERVICE

REF NO.	AT03109
DATE	Jun. 24, 2003
`	Page 1 of 6

SUBJECT: REPAIR PROCEDURE OF FUEL PIPE IN FUEL TANK ON WA1200-3

PURPOSE: To introduce modification procedure to repair the fuel suction tube posi-

tioned inside the fuel tank on WA1200-3 wheel loaders

WA1200-3 Wheel Loaders, Serial Nos. 50001 thru 50012 **APPLICATION:**

FAILURE CODE: 0426HA

DESCRIPTION:

1. Introduction

There is a possibility of occurrence of cracks in the welded section of the fuel suction tube positioned inside the fuel tank on the WA1200-3 wheel laders owing to insufficient strength, leading to fuel suction failure by that it may be once i possible to start the engine.

To repair the above failure, replace the fuel suction take hellowing the modification procedure being outlined in this Service News.


2. List of parts

Part No.	Part Name	Prapose of part	Q'ty	Remarks
42C-04-11420 (428-04-11120)	Tube (Cover)		1 (1)	
42C-04-11390 (42C-04-13551)	Bracket (Bracket)	Replacement	1 (1)	
01010-81230 (01435-01220)	Bolt Bo ^l t)		2 (2)	
01643-3123	Washer	Addition	2	
07102-2 433 (07102 21425)	Hose (Hose)	Replacement	1 (1)	
07040-14220	Plug	Addition	1	
42C-04-13880 (42C-04-13570)	Union (Elbow)	Replacement	1 (1)	

Part No.	Part Name	Purpose of part	Q'ty	Remarks
42C-04-13590 (42C-04-13590)	Elbow (Elbow)		1 (1)	
42C-01-12690 (42C-01-12690)	O-ring (O-ring)		1 (1)	
07283-36155 (07283-36155)	Clip (Clip)		1 (1)	
01597-01009 (01597-01009)	Nut (Nut)		2 (2)	
01643-31032 (01643-31032)	Washer (Washer)		2 (2)	Reuse the removed parts.
42C-04-13542 (42C-04-13542)	Cable (Cable)		1 (1)	CO,
04256-40615 (04256-40615)	Joint (Joint)		1 (1)	60.
01594-00606 (01594-00606)	Nut (Nut)			
01643-30623 (01643-30623)	Washer (Washer)		(1)	
(42C-04-13561)	(Bracket)		(1)]
(01435-01220)	(Bolt)	No'ved	(2)	Remove these parts.
(415-01-11120)	(Bracket)		(1)	
04434-51210 (04434-51210)	Clip (Clip)		1 (2)	
01435-01016 (01435-01016)	Boli (B.\lt)		1 (3)	
(01643-31032)	(Washer)	Not wood	(1)	Domest the seconds
(01580-01008)	(P.ut)	} Not used	(1)	Remove these parts.
07000-F3.48	O-ring	Addition	2	Parts which will be damaged while the brake
				cooler is being removed.


3. Details of the modification

The fuel suction tube positioned inside the fuel tank is to be changed from the current type which is being welded to the fuel tank directly to a new type which is to be welded to the hand hole cover thus making it possible to change the fuel suction tube. The welded section to the hand hole cover is also being reinforced.



4. Modification procedure


(1) Preparations before starting the replacement work for the fuel suction tube Since the new fuel suction tube will come underneath the fan guard and the brake oil cooler, it becomes necessary to remove the fan guard and the brake oil cooler before starting the replacement work.



(2) Removal of the parts

Remove the parts shown in Fig. 1 and Fig. 2 below.

Parts marked \Rightarrow are to be discarded and parts marked \times are to be reused.



(3) Installation of the parts

Install the parts as per the instructions given in the drawing below.

• Regarding the tightening torque for the bolts, refer to the Section "Standard tightening torque for bolts and nuts" in the Chapter "Inspection and Maintenance" in the Operation and Maintenance Manual.

Parts marked * are reusing parts after removal. Parts marked \otimes are newly prepared parts.

