PARTS & SERVICE NEWS

REF NO. | AA02171

DATE July 26, 2002

Page 1 of 2

SUBJECT: SWITCH FOR CRANKCASE PRESSURE (P/N 655 427 40)

PURPOSE: Improved lifetime conditions

APPLICATION: H255 Hydraulic Shovel, S/N's up to 06183 H285 Hydraulic Shovel S/N's 78105, 78106, 78129, 78133 and 78142 H455 Hydraulic Shovel S/N's from 15003 to 15005 PC3000 Hydraulic Shovel S/N's up to 06183 PC5500 Hydraulic Shovel S/N's from 15003 up to 15005

FAILURE CODE: 0100FA

DESCRIPTION:

Changing the installation of the switch for the crankcase pressure creates the following advantages:

- Lower stress for the pressure switch
- Extended lifetime of the pressure switch.

Procedure (see attached photo):

- Remove metal plate (1)
- Drill a hole diameter 14.95 mm
- Tap thread 3/8 pt
- Install a 3/8" street "L" (2) with teflor sealing
- Disconnect the old pressure switch
- Remove the pressure switch (4) from the old place and install the plug (5) by using teflon sealing.
- Install the pressure switch (=) in the new location by using teflon sealing.
- Reinstall the metal plate with stal (3)
- Reconnect the pressure switch

Required par.s	Part Number	Position Number
eal	906 810 40	3
Street "L' (45 degree)	516 668 98	2
Plug	517 217 98	5
Teflon sealing		



